

## IMPORTANT SAFEGUARDS

### Warning:

INSTALL THE LED CANOPY IN ACCORDANCE WITH APPLICABLE ELECTRICAL CODES BY PROFESSIONALS WHO ARE FAMILIAR WITH THE PRODUCT AND ITS ASSOCIATED HAZARDS. THE LED CANOPY MUST BE INSTALLED USING UL-LISTED CONDUIT FITTINGS.


- Risk of fire or electric shock.
- Make sure the working voltage of LED Canopy is under its rated voltage.
- Make sure the accessories and wires are completed and intact during the installation.
- Installation requires knowledge of electrical systems. Installation must be performed by a certified electrician. Do not attempt installation unless qualified.
- This fixture should only be installed in place of existing luminaries, that have the construction features and dimensions specified in this manual.
- Do not expose any wire to edge of sheet metal and/or other sharp objects that may cause damage or abrasion.
- During installation, do not change the fixture's or its components' existing open holes or create new ones.

### Cautions:


- Make sure the power is turned off before and during installation and maintenance.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- Do not use the LED Canopy near heating appliances/ elements.
- The input voltage and lamps should be matched after connecting the power line, please make sure the wiring section is insulated.
- LED Canopy must be operated within an ambient temperature range of -22 °F ~ +113 °F.
- LED Canopy is not intended for use with emergency exits.

### Installation:


#### Surface Mount Installation



1. Secure one side of the safety cord to the back of the radiator.




2. Use the hole cutter to cut the corresponding sized holes in the ceiling.




3. Fixed the safety rope on the ceiling. Making a wiring connection according to the wiring diagrams. Fixed the Fixture on the ceiling with bolts and nuts. Installation is done.


#### Selectable CCT & Wattage Function



1. Unscrew the Cap.




2. Adjust the CCT selectable DIP switch or the wattage selectable DIP switch accordingly.




3. Tighten the cap.

#### Sensor Function Installation:



1. Unscrew the cap.



2. Tighten the motion sensor.